

INSTRUCTION  
MANUAL

ROULETTE  
POKER  
**GRAND PRIX**  
MIRABEAU

I'IONACO

## INDEX

INTRODUCTION	3
AN EVERYDAY STYLE ACCESSORY	5
MONACO HERITAGE	7
GRAND PRIX	9
TECHNICAL INFORMATION	11
MOVEMENT SPECIFICATIONS	13
SETTING TIME AND DATE	15
WATER RESISTANCE LEVELS	17

## INTRODUCTION

The French Riviera, with its enchanting blend of Mediterranean coastline and glamorous cities, has long been a source of inspiration for artists, writers, and dreamers alike. Its picturesque landscapes, vibrant colors, and captivating ambiance have the power to ignite the imagination and awaken the creative spirit within.

From the sun-drenched beaches of Cannes to the luxurious allure

of Monaco, the Riviera exudes a timeless elegance that evokes a sense of romance and exclusivity.

It is a place where the soul finds respite and the artistic spirit finds its muse.

The captivating light that bathes the region is among the elements the brand has collected and used to create its charming watch collections.



AN EVERYDAY  
STYLE ACCESSORY

Monaco watch collections are designed in the pursuit of elegance, aplomb, and authenticity, they are all inspired by the city-state's storied past, vibrant present, and auspicious future and manifest style and function while designing the world's next luxury timepiece.

Our designs reflect the glint in your eye and withstand the test of time. Monaco is equal parts inspirational and aspirational. Every design is inspired by Monaco's depth of culture, and each one aspires to the region's singularity. Like the world travelers of centuries past, we seek the Riviera's unwavering, unparalleled élan.



The three vertical segments in Monaco's logo form the letter M, and our brand colors honor the city-state's flag. In addition to representing the Principality's elegant and refined style, our logo evokes upward movement in pursuit of growth and innovation.

The French Riviera is a truly special place—the ever-present sea breeze and light imbue the region with a unique, unrelenting charm. Monaco's dynamism and joie de vivre are our true inspiration.



## PASSION FOR SPEED AND PRECISION

The Principality's highest-profile event is perhaps the Formula 1 Monaco Grand Prix: the annual motor race enlivening the street circuit each May.

The Grand Prix emphasizes elegance and athleticism. Super-LumiNova markers and hands offer highly legible graphics, and the anti-reflective sapphire crystal allows the dial to be seen clearly in all light conditions. The 3

o'clock, two-tone counter pays homage to the Monegasque flag, and the red and blue stopwatches supplement the design's dedication to sport.

The case back features an engraving of the legendary Monaco street circuit; like the crown, the background of the case back mimics the geometric pattern found on the Monegasque Royal Coat of Arms.





- Quartz movement
- Quick date setting
- Display by means of hand hours, minutes and central seconds
- Screw-down caseback and crown
- Red start and stop push button and blue reset push button
- Personalized counter at 3 o'clock with the Monegasque flag colors
- Dial indexes, hours and minutes filled with SuperLuminova.

## TECHNICAL INFORMATION

<b>Case:</b>	Stainless steel 316L
<b>Diameter:</b>	42 mm
<b>Thickness:</b>	12.25 mm
<b>Lugs:</b>	20 mm
<b>Sapphire crystal:</b>	Yes
<b>Water resistance:</b>	100 mt / 10 ATM
<b>Dial finishing:</b>	Soleil
<b>Dial color:</b>	Black/Blue/Silver (Blue/Red)

MOVEMENT  
SPECIFICATIONS

## Miyota 6S20

Size ligne:	15
Height mm:	4.90
Accuracy per month:	-±20 sec
Battery life:	4 years

SETTING TIME  
AND DATE

In normal position 1 (wearing position) the crown is positioned against the case, the crown ensures that the watch is water-resistant.

**0. Screw in position** .....

**1. Unscrewed /Manual winding** .....


**2. Setting the date** .....

**3. Setting the time /** .....

**Set CHRONOGRAPH hands to reset**

**Push A - Start and stop the chronographer**

**Push B - Reset the chronographer** .....



ATTENTION: IF THE CROWN IS NOT SCREWED-IN (POSITION 0) WATER CAN PENETRATE INTO THE MOVEMENT AND DAMAGE IT PERMANENTLY.

Push A or B to set the hands to the zero position. The chronograph hands can be advanced rapidly by continuously pressing button. A for the Center Chronograph Second hand, B for 1/20 hands





## WATER RESISTANCE LEVELS



Accidental splashes



Splashes, shower & swimming



Swimming & snorkelling



Swimming, water sports & scuba diving



Scuba & saturation diving

MONACO-WATCHES.COM

